

9001-Strip: SaniDate® 5.0

BioSafe Systems' Peroxyacetic Acid Test Strips

BioSafe Systems' Peroxyacetic Acid (PAA) test strips instantly determine if your chemical program is within effective range.

Steps to Determine PPM for SaniDate 5.0

1. Using a cup-size sample, immerse the test strips
2. Remove with pads face up
3. Do not shake off excessive water
4. Wait 10 seconds and compare to color chart immediately
5. Discard strip after 30 seconds

When using SaniDate 5.0, SaniDate 15.0 or SaniDateFD as a produce wash, the test strip should give an indication between 20–100 ppm.

Tips: Keep wet fingers out of the vial. Close vial tightly after removing strip. Store in a cool, dry place.



Item Number

9001-Strip

Description

PAA disposable test strips

Application

10–160 ppm

1.888.273.3088 | biosafesystems.com

SaniDate® is a registered trademark of BioSafe Systems, LLC.
Always read and follow label directions.

©2018 Copyright BioSafe Systems LLC. All rights reserved. EQ18-04



Scan to
learn more